



Mounting instruction
Triumph Classic Dynamic chain tensioner
(code 307550)



Installation time : 5 minute
Tools Requirement : 1) 6mm. Allen wrench



1 Insert bottomhead bolts m10x45 in the holes of the frame as in the photo



2 Insert shims as photos.



4



Position chain tensioner by aligning the threaded holes.

5



Secure the chain tensioner.

Triumph Classic Chain Tensioner

Code: 307550

