



INSTALLATION



LED MIRROR LIGHTS FOR GL1800 7513

ATTENTION! THE LED MIRROR LIGHTS ARE MADE TO BE "PLUG AND PLAY" COMPATIBLE WITH KÜRYAKYN LIGHT BARS. WHILE THE LED MIRROR LIGHTS ARE ALSO COMPATIBLE WITH ORIGINAL LIGHTS, OR CAN BE USED ALONE, THEY WILL REQUIRE HARD WIRING TO THE BIKE'S STOCK WIRING HARNESS UNLESS YOU ORDER TWO PLUG AND PLAY ADAPTERS, P/N 607312P, SOLD SEPARATELY.

PARTS INCLUDED

- 2 LED Mirror Lights
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

PLEASE NOTE

It is the installers' responsibility to make sure all fasteners (including pre-assembled) are tightened before operation of motorcycle. Kuryakyn will not warranty components that are lost due to improper installation. Periodic maintenance may be required.

TOOLS SUGGESTED

Phillips screwdriver, Wire stripper, Soldering supplies, Electrical tape

PROCEDURE

STEP 1 See PIC.1. Insert your Phillips screwdriver into the hole on the bottom of each mirror housing and remove the Phillips screw that holds the mirror assembly in place. Loosen or remove the mirror assembly.

NOTE

If Kuryakyn "Light Bars" are being installed with these mirror lights, the mirror lights may simply be plugged into the connector that comes with the Light wiring. Proceed to STEP 4.

If these lights are used with the original Lights without the plug in connection or used by themselves, cut the plug off, and proceed with STEP 2 through STEP 4.

STEP 2 See PIC.2. Cut back some of the vinyl enclosure that surrounds the three turn signal wires in each mirror housing.

-cont.-

PIC.2



PIC.1



7513-15GL-0207

CUSTOMER SERVICE

877.370.3604 (toll free)

INSTALLATION QUESTIONS

techsupport@kuryakyn.com
or call 715.247.2983

LIMITED WARRANTY

Kuryakyn warrants that any Kuryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Kuryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
- The product must be properly installed, maintained and operated under normal conditions.
- Kuryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
- Kuryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Kuryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Kuryakyn and a customer.
- Kuryakyn products are often intended for use in specific applications. Kuryakyn makes no warranty if a Kuryakyn product is used in applications other than intended.
- Kuryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. Components of Kuryakyn products containing L.E.D.s will be warranted for defects in materials and workmanship for 3 years from the date of purchase.
- Kuryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Kuryakyn. Kuryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

ABOUT OUR CATALOG

You'll find all our innovations for H-D, GL and Metric Cruisers in our annual catalogs. Order online today—select the "CATALOGS" icon. Each Kuryakyn product comes with a Proof-of-Purchase good for a complimentary catalog. Details in packaging.

Be sure to ask your local dealer about other Kuryakyn products, the motorcycle parts and accessories designed for riders by riders.

©2005 Kuryakyn USA All Rights reserved.



STEP 3 See PIC.3. DO NOT fully cut any of the bikes OEM wiring.

LEFT SIDE: Skin back a little of the insulation on the green and orange wires. Splice the black wire from the LED harness to the green wire on the bike's stock harness. Splice the black and white wire from the LED harness to the orange wire on the bike's stock harness. Carefully solder and insulate your splices.

RIGHT SIDE: Skin back a little of the insulation on the green and light blue wires. Splice the black wire from the LED harness to the green wire on the bike's wiring harness. Splice the black and white wire from the LED harness to the light blue wire on the bike's wiring harness. Carefully solder and insulate your splices.

STEP 4 See PIC.4. Trial fit the light pod on the mirror to determine the points where the adhesive pads will rest on the mirror back. Thoroughly clean this area with windex, alcohol, etc. and let dry. Remove the adhesive backing and permanently affix the light pods to the mirror as shown. Test the light by activating the turn signal. Re-install the mirror in the housing.

Ride On!

Kuryakyn

PIC.3



PIC.4



PAGE

2