

# INSTALLATION

# PASSENGER FLOORBOARDS

4455

FITS: UNIVERSAL APPLICATIONS – REQUIRES MODEL SPECIFIC SPLINED ADAPTERS, SOLD SEPARATELY REFER TO KURYAKYN'S FULL-LINE CATALOGS OR VISIT WWW. KURYAKYN.COM FOR ADAPTER APPLICATION INFORMATION.

#### PARTS INCLUDED

- 1 Right Side Passenger Floorboard
- 1 Left Side Passenger Floorboard
- 1 Hardware Kit, including:
  - 2 5/16-18 x 3/4 Socket Head Cap Screw (SHCS)
  - 2 Anti-Seize Packet
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

#### THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

WARNING! THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE

CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR

SERIOUS INJURY.

CAUTION! This indication alerts you to the fact that ignoring the contents described herein

can result in potential injury or material damage.

ATTENTION! This indication alerts you to the fact that ignoring the contents described herein

may negatively affect product performance and functionality.

## **TOOLS SUGGESTED**

Set of hex wrenches

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

#### **PROCEDURE**

**STEP 1** Park the motorcycle on a hard, level surface; turn off the ignition and allow the engine to cool.

**STEP 2** Remove the existing passenger footrests; save the mounting hardware for later use.

**STEP 3** Install the model specific adapters (sold separately) and secure with the hardware from STEP 2. Refer to the instructions included with the new adapters for more information.

-cont.-

#### **CUSTOMER SERVICE**

877.370.3604 (toll free)

# **INSTALLATION QUESTIONS**

techsupport@kuryakyn.com or call 715.247.2983

#### **LIMITED WARRANTY**

Küryakyn warrants that any Küryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

 Küryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).

• The product must be properly installed, maintained and operated under normal conditions.

· Küryakyn makes no warranty, expressed or implied, with respect to any gold plated products.

 Küryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Küryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breech of contract or duty between Küryakyn and a customer.

> Küryakyn products are often intended for use in specific applications. Küryakyn makes no warranty if a Küryakyn product is used in applications other than intended.

Küryakyn electrical products are warranted for one
(1) year from the date of purchase by the consumer.
Components of Küryakyn products containing L.E.D.s
will be warranted for defects in materials and
workmanship for 3 years from the date of purchase.

Küryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Küryakyn. Küryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

## **ABOUT OUR CATALOG**

You'll find all our innovations for H-D, GL and Metric Cruisers in our annual catalogs. Order online today–select the "CATALOGS" icon. Each Küryakyn product comes with a Proof-of-Purchase good for a complimentary catalog. Details in packaging.

Be sure to ask your local dealer about other Küryakyn products, the motorcycle parts and accessories designed for riders by riders.

©2005 Küryakyn USA All Rights reserved



**NOTE** Some adapters include hardware and do not utilize the original fasteners.

ATTENTION! Ensure that the supplied anti-seize is applied to all threaded fasteners before installation; this will make future removal of the fasteners easier.





**STEP 4** Put a small amount of the included anti-seize on one of the 5/16-18 SHCS.

**STEP 5** Hold the Passenger Floorboards in position and insert screw from STEP 4 as shown in <u>PIC.1</u>. Do not thread the screw in all the way to allow for adjustment of the floorboard.

**STEP 6** Adjust the angle of the floorboard for comfort and clearance; tighten the screw from STEP 4 and STEP 5. Ensure that the splines on the Passenger Floorboard and the splined adapter fully engage when the screw is tightened.



Küryakyn

CAUTION! Ensure that the installation of this product does not interfere with the proper operation of the motorcycle before riding.

**STEP 7** Repeat STEP 4 through STEP 6 for the other side.

WARNING! IMPROPER INSTALLATION OR USE OF THIS PRODUCT COULD RESULT IN SERIOUS INJURY OR DEATH.

ATTENTION! It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Küryakyn will not warranty components lost due to improper installation. Periodic maintenance may be required.

Ride On!

PAGE 2