

FORWARD CONTROL SPACER SET
FOR HARLEY-DAVIDSON SOFTAIL (2000-2017)
WITH TB FORWARD CONTROLS



PACKING LIST:

amount	item
1	Spacer left
1	Spacer right
6	Flat head screw UNC 3/8*2

MOUNTING INSTRUCTIONS:



Place the spacers (A) between the frame and the backplate of the foot controls during the installation of the TB forward controls.

Mount the backplates and the spacers together to the frame using the included flat head screws (B) and tighten them with 30-35 Nm (22-25,8 ft-lbs) torque.

Tip: The third screw is placed behind the brake master cylinder (hidden installation)!

Attention: The mounting screws of the forwards controls are not used further.

Mount the forwards controls according to their mounting instructions.

The Thunderbike team wishes you fun with your new parts.
Have a nice and safe ride!



Thunderbike
Güterstrasse 5
D-46499 Hamminkeln
Telefon(0049)2852 - 6777 - 33
Telefax (0049)2852 - 5444
info@thunderbike.de