

## **MOUNTING SUGGESTIONS:**

Harley-Davidson®
Sportster/Dyna/Softail 200mm/
Blackline/Slim - Fender Bib

Note: Mustang recommends removal of the fender bib before installing a passenger seat. Mounting a passenger seat over a fender bib may result in damage to the bib, poor seat alignment or other problems.

<u>Softail 200mm rear tire:</u> This bib fits with a Mustang solo only.

## <u>Installation of Mustang fender bib:</u>

- 1. Remove the seat from the motorcycle.
- 2. Position the fender bib on the fender.
- 3. Install the solo seat so the seat's rear bracket is on top of the bib. Insert a ¼"-20 screw through the bracket and bib into the fender mount. Leave this loose for now.
- 4. Secure the back of the bib with the stock rear screw.
- 5. Adjust the bib for best fit, and secure the solo mounting screw.

78061 shown



## Enjoy the custom look of your new Mustang fender bib!



These steps are guidelines to help you install your new Mustang product. If you need further assistance, please call us at 800-243-1392 or 413-668-1100, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "Support".

Refers to part numbers: 78030, 78031, 78055, 78056, 78060, 78061, 78104, 78105, 78117, 78118, 78143, 78144

## You are cordially invited to Tour the Mustang Factory.

See how our craftspeople take pride in transforming raw materials into the world's highest quality, most comfortable handcrafted seats. Please contact Mustang for more information regarding tours of our historic Three Rivers, Massachusetts, facility (only 75 miles west of Boston; 150 miles northeast of New York City). Our two hour tours are by reservation only; we can accommodate groups from 2 to 24. We promise you will ride away with an entirely new awareness of what you put between you and your bike.