



MOTORCYCLE SEATS

Mounting Suggestions: Harley-Davidson® Sportster 2004 - 2013 One-Piece Seat

Tools Required:
Phillips Screwdriver

Hardware:
Stock 1/4-20 Rear Fender Screw



Baseplate Features:

The one-piece marine grade fiberglass baseplate mounts using the stock rear fender screw. Vibration is minimized with the strategic placement of rubber bumpers.

Stock Seat Removal Steps

1. Remove the rear 1/4-20 fender screw with Phillips screwdriver and set aside. The stock rear fender screw will be used to attach your new Mustang One-Piece Seat.
2. Lift back of seat up about 1" then push seat forward until the slotted center of the seat releases from the frame's shoulder bolt. (Fig. I)

Fig. I



Mounting of Mustang Seat

1. Engage nose bracket into the frame at the base of the fuel tank, just like the stock seat. (Fig. II)
2. Secure rear of seat to the fender with stock 1/4-20 fender screw to complete the installation process. *Note: The Mustang Seat does not utilize the frame's shoulder bolt.*

Fig. II



Enjoy the Comfort of your new Mustang Seat!



These steps are guidelines to help you install your new Mustang product. If you need further assistance please call us at 800-243-1392, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "Support".

Refers to part numbers: 76140, 76141, 76144, 76145, 76146, 76147, 76374, 76375, 75543, 75544, 76142, 76143, 76290