



## ELLIPSE MIRRORS

# 1437

### PARTS INCLUDED

- 1 Left Ellipse Mirror Assembly—Flat Glass
- 1 Right Ellipse Mirror Assembly—Flat Glass
- 1 Hardware Kit, Including:
  - 2 5/16"-18 X 1-1/2" Socket Head Cap Screws
  - 2 5/16"-18 X 2" Socket Head Cap Screws
  - 1 2.5mm Hex Key Wrench
  - 2 5/16" Split Lock Washers
  - 2 5/16" Internal Tooth Lock Washers
  - 2 Double End Threaded Studs
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

### THANK YOU FOR CHOOSING KÜRYAKYN!

**IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND NOTICES REGARDING THE USE AND CARE OF THIS PRODUCT.**

<b>NOTICE</b>	<b>This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.</b>
<b>CAUTION</b>	<b>This indication alerts you to the fact that ignoring the contents described herein can result in potential injury.</b>

**NOTICE** IF INSTALLING THIS PRODUCT FOR ANOTHER PARTY, PLEASE MAKE SURE THEY RECEIVE THIS COPY OF THE INSTALLATION INSTRUCTIONS SO THEY ARE AWARE OF THE IMPORTANT INFORMATION CONTAINED IN THEM.

### TOOLS SUGGESTED

Set of Hex Wrenches, Set of Combination Wrenches

**STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.**

### ALL INSTALLATIONS

**STEP 1** Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition.

**NOTE:** The included 2.5mm Hex Wrench is used only in P/N 1428, 1430, 1437 & 1438 to adjust the swivel ball tension.

**NOTE:** Mirror adapters (sold separately) are required for installation on metric cruisers.

**NOTICE** Avoid damage to the motorcycle. Protect painted surfaces with a soft cloth or blanket.

### CUSTOMER SERVICE

877.370.3604 (toll free)

### INSTALLATION QUESTIONS

techsupport@kuryakyn.com  
or call 715.247.2983

### LIMITED WARRANTY

Kuryakyn warrants that any Kuryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Kuryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
- The product must be properly installed, maintained and operated under normal conditions.
- Kuryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
- Kuryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Kuryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Kuryakyn and a customer.
- Kuryakyn products are often intended for use in specific applications. Kuryakyn makes no warranty if a Kuryakyn product is used in applications other than intended.
- Kuryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. L.E.D.'S contained in components of Kuryakyn products will be warranted for defects in materials and workmanship for 3 years from the date of purchase where as all other components shall be warranted for one(1) year. This includes, but is not limited to; control modules, wiring, chrome & other components.
- Kuryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Kuryakyn. Kuryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

### ABOUT OUR CATALOG

For purchasing Kuryakyn® products, you can receive a complete catalog free of charge. Send the Proof-of-Purchase below with your address to: Kuryakyn, P.O. Box 339, Somerset, WI 54025. Please indicate either Accessories Catalog for Harley-Davidson® or GL & Metric Cruisers.

Be sure to ask your local dealer about other Kuryakyn® products, the motorcycle parts and accessories designed for riders by riders.

©2005 Kuryakyn USA® All Rights reserved.



## NOTICE

Ensure that the position of the mirror and stem **DO NOT** interfere with the operation of the motorcycle hand controls.

Küryakyn®

## NOTICE

It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Küryakyn will not provide warranty coverage on products or components lost due to improper installation or lack of maintenance. Periodic inspection and maintenance are required on all fasteners

**STEP 2** Remove the stock mirrors from controls; set them aside, they will not be re-used.

### MOUNTING WITH SINGLE SCREW

**STEP 3** Determine which of the included socket head cap screws from the hardware kit will provide maximum thread engagement in the mirror stem without bottoming out.

**STEP 4** Place a split lock washer over the socket head cap screw and insert it in the hole in the hand control. FIG 1

**STEP 5** Place an internal lock washer over the protruding end of the cap screw.

**STEP 6** While holding the mirror in place, thread the socket head cap screw into the bottom of the mirror stem.

**NOTE:** Ensure that the setscrew in the mirror stem does not prevent the socket head cap screw from being installed fully. FIG 1

**STEP 7** Adjust the position of the mirror stem for visibility and clearance; tighten the socket head cap screw and then the setscrew.

**STEP 8** Repeat STEP 3 through STEP 7 for the opposite side.

**STEP 9** Adjust the mirrors for proper view before riding the motorcycle.



### H-D with Bottom Mounted Turn Signals—Right Side Procedure

**CAUTION** Removing the retainer nut and/or the ball stud clamp in the next Step will release the turn signals from the hand controls. Secure the turn signals to prevent damage or injury.

**STEP 10** Loosen and remove the retainer nut and ball stud clamp shown in FIG 2

**STEP 11** Remove the stock mirror; hold the stock turn signal to prevent it from being damaged.

-cont.-



**STEP 12** Screw a double ended stud into the new mirror stem; tighten and then tighten the set screw.  
FIG 2

**NOTE: Ensure that the setscrew in the mirror stem does not prevent the double ended stud from being installed fully. FIG 2**

**STEP 13** Place an internal lock washer over the long end of one of the double-ended studs; insert the assembly into the mirror stem hole in the hand control. FIG 2

**STEP 14** Place a split lock washer over the protruding end of the double-ended stud and thread the retainer nut onto the stud. FIG 2

**STEP 15** Adjust the position of the mirror stem for visibility and clearance; tighten the retaining nut.

**STEP 16** Install the ball stud clamp onto the retainer nut; adjust the turn signal and tighten the clamp.

**STEP 17** Repeat STEP 3 through STEP 7 for the LEFT SIDE.

**STEP 18** Adjust the mirrors for proper view before riding the motorcycle.

**ADJUST SWIVEL BALL TENSION**

**STEP 19** Remove the mirror head from the stem using an open end wrench on the flat on the end of the ball stud. PIC 1 Using the included hex wrench, remove the two fasteners from the back of the mirror cover; PIC 2 carefully remove the front bezel and mirror glass.




**NOTE: Make sure the hex wrench is fully seated in the bolt before you try to loosen the two bolts. Improper fitting wrenches will strip the head on these bolts!**

**STEP 20** Turn the tension screws inside the mirror housing (PIC 3) to increase or decrease the tension on the ball joint. Turn the screws clockwise to increase tension; turn the screws counter-clockwise to decrease tension. Place a drop of light lube (WD-40) on ball. PIC 3

**STEP 21** Replace the mirror glass and bezel to the back cover, secure with the two fasteners removed in Step 19.

**STEP 22** Reinstall the mirror head to the stem.

**STEP 23** Tighten all fasteners securely.



**NOTICE**

It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Küryakyn will not provide warranty coverage on products or components lost due to improper installation or lack of maintenance. Periodic inspection and maintenance are required on all fasteners.